

# ProSpray™

## Surface Disinfectant



Lemon  
Scent

## Ready-to-Use Automotive Cleaning / Disinfecting



ProSpray is a ready-to-use surface disinfectant and cleaner in one product. Hospital grade disinfectant that is safe for use in the automotive industry.

### How to clean and disinfect hard surfaces including dash, steering wheel, door handles, seats, seat belts, plastic controls, and more:

1. Turn sprayer nozzle to desired narrow or wide spray pattern.
2. Use sprayer to apply ProSpray directly on surfaces or apply ProSpray by spraying or squirting into clean disposable towels or clean cloths to wipe surfaces.
3. **For light soil, clean and sanitize in one step:** Apply ProSpray. Allow one minute wet dwell time. Air dry or wipe off.
4. **For heavy soil, clean and sanitize in two steps:** First, use ProSpray to remove soils. Second, use fresh cloths or paper towels to re-apply ProSpray lightly. Allow one minute wet dwell time. Air dry or wipe off.
5. **CAUTION: Do not spray directly into electronic ports or connections.** Spray or squirt ProSpray on clean disposable towels or clean cloths to apply around electronics.
6. ProSpray may be used on vinyl or leather upholstery. After cleaning and sanitizing, follow up with a final wipe off with water dampened paper towels or cloths.

7. **Porous cloth upholstery and headliners:** Use recommended cloth upholstery cleaners. If sanitizing is desired for porous surfaces, spray ProSpray lightly over clean porous materials and do not saturate. Allow one minute dwell time.
8. **Exterior door handles or other exterior surfaces:** Clean first with recommended cleaners for car finish. Spray or squirt ProSpray into cloths or paper towels, then apply to door handles or other surfaces where sanitizing is needed. Allow one minute wet dwell time. Rinse off with fresh wet paper towels or wet cloth.
9. **Use with spray gun:** Use proper PPE, mask/respirator and protective eyewear. Open all doors and windows, lightly spray all non-porous surfaces. Keep doors and windows open for 30 minutes after use for ventilation. If residue has built up, use a dampened soft cloth/towel to wipe surface. If used on porous surfaces, like seats or floor mats, vacuum these surfaces to eliminate excess product.
10. **For interior surfaces soiled with blood, vomit, urine or other body soils:** Wear mask and gloves. Remove as much soil as possible with wet disposable towels. Use an enzyme based detergent cleaner to remove additional soils and stains. Rinse or wipe with wet disposable towels. Disinfect with ProSpray allowing a five-minute wet dwell time. Rinse or wipe off.

### ProSpray Ready to Use Disinfectant:

- EPA registered hospital grade - hard on germs but gentle enough to use with bare hands.
- Cleaner and disinfectant in one product.
- Compatible with most materials including vinyl, metals and plastics.
- No solvents, no bleach, not corrosive.
- Easy to use with light lemon scent.
- Kills 99.9% of viruses and bacteria in 1 minute

### Economical Choice:

- One gallon and five gallon refills available.

